

Water contamination can occur in various forms. From steam and humidity, to drops, to full submerging, water contamination incidents pose a unique set of challenges for businesses and insurers. Rapid response in properly stabilizing electrical equipment after water exposure should be of utmost importance for all stakeholders to increase the likelihood of successful restoration in the weeks following.

Here are expert suggestions to stabilize equipment following a water contamination incident:

- Disconnect the electricity supply to equipment, including UPS systems/backup battery supplies.
- Remove excess water by mopping or wiping. 'Wet-type' vacuum cleaners can be used for removing large quantities of water from widespread areas. Do not forget to remove water under raised floors and in electrical ducts.
- Framove wet objects, such as packaging materials, etc. from the affected areas.
- Have qualified personnel open equipment and remove surface water where visible. For example, open equipment covers and remove all water from inside the equipment.
- Install dehumidifiers in the areas where the affected equipment is located, and reduce the humidity to around 45% 55% RH. If dehumidifiers are not available, use fans to circulate air through the affected areas.
- Apply a metal preserving compound (e.g. oil, grease or WD-40) to unprotected metallic surfaces on machinery to stop, or slow down, corrosion.

To contact an AREPA restoration specialist, visit www.arepa.com.